




iTube
5141 962B




5141 962 314 B	25,4W.	3.637	143,2lm/W.	spot	3.000
5141 962 324 B	25,4W.	3.637	143,2lm/W.	medium	3.000
5141 962 338 B	25,4W.	3.637	143,2lm/W.	flood	3.000
5141 962 414 B	25,4W.	3.785	149lm/W.	spot	4.000
5141 962 424 B	25,4W.	3.785	149lm/W.	medium	4.000
5141 962 438 B	25,4W.	3.785	149lm/W.	flood	4.000
code	module W	lm	efficiency	beam angle	°K



pedido_order

5141	962	4	14	8
code	25,4W	°K	beam angle	color



colores_colors 1T

materiales_materials
aluminio extruido y acero
extruded aluminium and steel

J315061131
J315061133
J315061138
J315061135
J315061137-0X

frontal 
incluido en color de proyector
included in spot color

V31506111
V31506113
frontal plano 
no incluido
not included

X112015002 transparente
X112015003 satinado
cristal 
no incluido
not included

Este modelo viene equipado con un frontal del mismo color que el solicitado para el proyector. Para otras opciones de color, el modelo de frontal plano, o el cristal de protección, es necesario realizar un pedido aparte.






5141 | iTube


válido para todos los proyectores con adaptador a carril trifásico
valid for 3 phase track adaptor spots

INSTRUCCIONES_INSTRUCTION




Esta luminaria no es apta para colocar en los perfiles 3553 y 3556 de la familia slot.
Antes de montar el adaptador en el carril, asegúrese de que la corriente está cortada.
Fijar el proyector en el carril trifásico conectando correctamente el adaptador.

This luminaire is not suitable to be placed in 3553 and 3556 slot family profiles.
Before installing the adapter into the track, make sure the power is switched off.
Connect the spotlight into the triphasic track by plugging its adaptor correctly.




Comprobar la posición correcta para evitar daños.
Bloquear la leva en la posición correcta.

Check the right position to avoid damage.
Lock the lever to its correct position.



Ajustar el dial en el circuito o fase correcta.

Adjust the wheel to the correct phase / circuit.



Orientar la luminaria.

Adjust the fixture.